


INSTRUCTION
MANUAL
BOOK

ELECTRIC PALLETTRUCK

SEPT



48V (20A/32A)	
Frame size	685 x 1150 mm
Vehicle length	1660 mm
Fork length	1150 mm
Lifting range	80-200 mm
Motor type	High power brushless motor 1000W
Driving speed	5 km/h (OR 2km/h)
Wheel size	Big wheel 180 x 65mm Small wheel 80 x 50mm

Unplug the power-off plug when it is not working to ensure the maximum life of the battery. The battery pack can be charged on the vehicle or can be charged anywhere. Solve the problem that there is no power to charge on site.

Note: if the battery is not used for a long time, it needs to be charged every 10-15 days. If the battery is placed for too long, it will not be charged. If the battery is placed for too long, it will become invalid or the battery with a bulging bag will not be guaranteed. If it is not used for a long time, you need to open the battery cover and disconnect the positive and negative power supply of the battery, which can make the storage time longer!

Reminder:

The power supply must be equipped with a leakage protection switch.

Please read the instruction carefully before use.